

Fastronix Deutsch Style Connector Instructions

Plug
Connector



Plug Contact



Plug Wedge



1. Crimp or solder wire on to contact.
2. Grasp crimped contact wire approx. one inch behind the contact.
3. Push contact **(plug or recept)** straight into correct **(plug or recept)** connector back (orange seal) until a 'click' is felt.
4. A slight tug will confirm placement.
5. Repeat steps 1-4 for all contact pins.
6. Insert correct wedge **(plug or recept)** into connector front.
7. A 'click' will be felt when the wedge is fully installed.

More Info: www.fastronixsolutions.com

Recept
Connector



Recept
Contact



Recept
Wedge

