

Fastronix #600-010 Open Barrel Crimper

Use with Fastronix connector terminals listed.

1. Strip wire and insert in terminal 2. Use end of crimp tool and slightly squeeze the terminals open barrel end straight to hold wire and aid in fitting in crimp slot. 3. Install in correct **WIRE** crimp slot (per chart), resting terminal on the rounded groove next to correct numbers with open side of terminal facing up. 4. Squeeze to form crimp on wire. 5. Install in correct **INSUL** crimp slot (per chart) resting terminal on the rounded groove next to correct numbers with open side of terminal facing up. 6. Squeeze to form crimp on insulation.

Note: On WeatherPack terminals slide seal on wire first. After crimping slide seal over insulation crimp.

CRIMP SLOT GUIDE CHART

Wire Size	FASTRONIX TERMINAL							
	Deutsch Style		Weather Pack		Relay Socket Kit		Rocker Sw Socket Kit	
	Wire	Insul	Wire	Insul	Wire	Insul	Wire	Insul
18G	18-20	20-24	22-24	20-24				
16G	18-20	14-16	18-20	14-18	18-20	14-18	18-20	20-24
14G	18-20	14-18	18-20	14-18	18-20	14-18	18-20	20-24
12G			14-16	14-18				