

**Plug
Connector**



Plug Contact



Plug Wedge



1. Crimp or solder wire on to contact.
2. Grasp crimped contact wire approx. one inch behind the contact.
3. Push contact **(plug or receipt)** straight into correct **(plug or receipt)** connector back (orange seal) until a 'click' is felt.
4. A slight tug will confirm placement.
5. Repeat steps 1-4 for all contact pins.
6. Insert correct wedge **(plug or receipt)** into connector front.
7. A 'click' will be felt when the wedge is fully installed.

More Info: www.fastronixsolutions.com

**Receipt
Connector**



**Receipt
Contact**



**Receipt
Wedge**



:
or

